## **QUICK SETUP**



Model: HT-S3100/HT-S3105

Thank you for purchasing this product.

This quick setup sheet shows the typical hookup method for connecting speakers and AV components (DVD player, TV, cable/satellite receiver). For more detailed hookup information and operating instructions, please see the Instruction Manual.

## First of all, turn on speaker set A.




On the front panel

Press the SPEAKERS [A] button on the front panel. Make sure that speaker indicator A is shown on the display.


On the display

Turn off speaker set B when not in use. Indicator should be off.

### Speaker Set A Layout (Main Room)



### Speaker Set A Hookup



HTP-360 speaker package is shown


See the other side of this sheet for the AV component hookup.



# **AV Component Hookup**




A TV, DVD player, and cable/satellite receiver is used in this hookup example. See the Instruction Manual for how to connect other types of components.



### **Assigning the Digital Input**

If there's no sound, press the [DIGITAL INPUT] button repeatedly until sound is heard. The digital input is now properly assigned.

If you connect your DVD player to the AV receiver's **COAXIAL DIGITAL IN, and your cable/satellite receiver** to the OPTICAL 1 DIGITAL IN, as shown, it's not necessary to assign the digital input.



See the other side of this sheet for the Speaker hookup.

